

### **BEFORE DRIVING INSPECTION BEFORE EVERY RIDE:**

- The battery charger is disconnected from the mains. (Do not use extension cords or reels)
- The battery is sufficiently charged. (tank symbol indicates 64 – 66V)
- The lights and horn work properly.
- The mirror is correctly adjusted.
- Tires are at the correct pressure (2.5 bar) and have sufficient tread depth.
- The brakes are working properly (test while pushing).
- Steering angle to the left and right is sufficient and goes without resistance.

### **DRIVING SKILLS:**

- Take a seat on the E-Chopper and turn the ignition key 1 click to the right; 2 clicks to the right turns on the lighting.
- Fold the kickstand; the motor will not work with the stand extended. Caution: the electric motor does not make any noise, but the throttle is active.
- Gently twist the throttle to drive away and get used to steering with the wide tires.
- Drive carefully and responsibly.
- Always keep two hands on the wheel.
- Always brake with both brake levers not at once, but pumping!

### **CONDITIONS:**

- Driver must be in possession of a valid moped, scooter or a driver's license.
- In case of damage, violation or a collision, contact the lessor immediately.
- The maximum driving distance (range): 50 – 55km.
- Maximum 1 person – maximum load: 120 kg including luggage.