

## PLACA COCINA / COOKER

Las ilustraciones muestran la explicación de botones y controles. Para garantizar el correcto uso de la cocina, utilice las sartenes y ollas que encontrará en el alojamiento.

1. Primero coloque la sartén/olla en el lugar correspondiente y pulse (+) para ir aumentando la potencia de la cocina, pulse (-) para reducir la potencia.
2. Cuando retire la sartén/olla si la superficie aun esta caliente aparecerá la letra H en la pantalla de la zona.

**IMPORTANTE** – La placa de cocina emitirá un sonido si se dejan objetos en su superficie, por favor, retirelos.

The illustrations show the explanation of buttons and controls. To ensure correct use of the cooker, use the pots and pans found in the housing.

1. First place the pan/pot on the right place and press (+) to increase the power of the cooker, press (-) to decrease the power.
2. When you remove the pan/pot if the surface is still hot, the letter H will appear on the zone display.

**IMPORTANT** - The cooker will beep if objects are left on its surface, please remove them.

### El panel de mando

